


Thermo-Control®

The ultimate wood burning system.



Sample Installation: Thermo Control Model # 500 with stainless steel water heating coils. Add on to existing gas or oil fired boiler with “tankless” domestic coil.

During heating season, close valve “C” and open valves “A” and “B”. This will divert the cool return water into the heated storage tank where it will pick up heated water and then send it into the gas/oil boiler.

The existing boiler will not fire when the water from the tank is warmer than the existing boilers settings which typically will be between 130° and 150° F.