


Thermo-Control®

The ultimate wood burning system.

Wood Boiler Water to Air Exchanger

New Thermostat, wired to start furnace blower



Items Not Pictured:

- 1) Fan Control Switch wired to furnace blower and new thermostat.
- 2) Ball valves on house supply as well as supply and return lines to exchanger, as desired.